

Indhold

Trådløs signal forstærker	2
Wireless signal repeater	3

Trådløs signalforstærker

Sluk for alarmcentralen, træk strømstikket ud og sæt ON/Off knappen på OFF. Sluk også for alle sensorer!

Trin 1. Kodning af trådløst udstyr til signalforstærkeren

1. Sæt strøm til signal forstærkeren og tænd for denne.
2. Tag den sensor du ønsker kodet og placer den ved siden af signal forstærkeren.
3. Under bunden på signal forstærkeren er der en knap, som hedder "Study" tryk på den.
4. Indikator lampen skifter nu fra rød til orange, hvilket betyder at signal forstærkeren er i kodnings tilstand.
5. Vift nu med hånden foran PIR sensoren(hvis det er en dør/vinduessensorer, fjern magneten fra basen).
6. Indikatorlampen på signal forstærkeren vil nu blinke 3 gange for at lade dig vide, at sensoren er kodet til den.
7. Tryk på "study" igen for at afslutte kodningstilstand.

Trin 2. Test signalforstærkeren

1. Tænd nu for alarmen igen, og vent på, at den begynder at lyse konstant grønt i statuslampen.
2. Aktiverer alarmen ved at trykke på den lukkede hængelås på fjernbetjeningen til alarmen.
3. Gå nu så langt væk som sensoren skal placeres fra alarmcentralen.
4. Aktiver for sensoren(hvis det er en PIR, så tænde på siden eller oven på den) og aktiverer PIR sensoren ved at vifte hånden foran PIR sensoren.
Hvis det er en dør vinduessensor så fjern magnet fra basen.

Wireless signal repeater

Firstly turn off the alarm main panel, by disconnecting the power adapter and by switching the ON/OFF button to OFF. Secondly turn off all sensors!

Step 1: Coding of wireless equipment

1. Connect the power adapter to the wireless signal repeater and turn it on.
2. Place the sensor you want to mount furthest away from the main panel, next to the wireless signal repeater.
3. On the bottom of the wireless signal repeater there is a button called "study" press it.
4. The indicator lamp on the wireless signal repeater will now change from red to orange, which indicates that the wireless signal repeater now is in code mode.
5. Turn on the PIR sensor and wave you hand in front of the sensor (if it is a door/window sensor you are coding then remove the magnet from the base).
6. The Indicator lamp on the wireless signal repeater will now blink 3 times which means that the sensor has been coded successfully.
7. Press the "study" button again to exit code mode.

Step 2: Testing signal repeater

1. Connect the power adapter to the alarm and switch the ON/OFF to ON.
2. Wait for the status lamp on the alarm main panel starts blinking green with fixed intervals.
3. Move to location, where the sensor you have just coded to the wireless signal repeater, is to be mounted.
4. Turn on the sensor (if it is a PIR turn it on, on the side) and activate it by waving your hand in front of the sensor
If it is a door window sensor simply remove the magnet from the base.